


| SW1 | CH2 | CH4 |
|------------|-----|-----|
| ON OFF 1 2 | | |
| ON OFF 1 2 | | |
| ON OFF 1 2 | | |
| ON OFF 1 2 | | |

Legenda

| | | |
|--------------|------------|----------------|
| | | |
| Monostabile | Bistabile | Timer |
| Monostable | Bistable | Timer |
| Monostable | Bistable | Temporisateur |
| Monostabile | Biestabile | Temporizador |
| Monostabil | Bistabil | Timer |
| Monostábel | Biestábel | Temporizador |
| Monostabil | Bistabil | Timer |
| Διακοπτόμενο | Συνεχές | Χρονοδιακόπτης |

| RELÉ | JUMPER | CH1 | CH2 | CH3 | CH4 |
|-----------|--------|-----|-----|-----|-----|
| K1 | 1 1 | | | | |
| | 1 2 | | | | |
| | 1 3 | | | | |
| | 1 4 | | | | |
| K2 | 2 1 | | | | |
| | 2 2 | | | | |
| | 2 3 | | | | |
| | 2 4 | | | | |



| | DRS4332 (AU02910) |
|--|-------------------|
| | 12 Vdc |
| | 15 mA |
| | 433,92 MHz |
| | 0,5 A / 24 Vdc |
| | -20°C / + 70°C |
| | Max. 200 |

| JP2 | | |
|-----|-------------|----------|
| | HCS Rolling | Standard |
| | HCS Fix | |
| | DIP Switch | |


D GR I UK F E

Scheda ricevente
Receiver board
ISTRUZIONI PER L'INSTALLAZIONE
INSTRUCTIONS FOR INSTALLATIONS

DRS4332 - (AU02910)



:DOMINO



www.gibidi.com

Numero Verde: 800.290156
E-mail: comm@gibidi.com
Fax +39.0386.52.20.31
Tel. +39.0386.52.20.11
46025 Foggia Rusco (MN) - ITALY
Via Abelone Brennero, 177/B
GIBIDI S.r.l.



a BANDINI INDUSTRIE company

G:B:D

